

## **INTO THE WILD SCREEN PRINTING PLASTISOL HEAT TRANSFER INSTRUCTIONS**

### **PRE USE INSTRUCTIONS**

- Cut off any excess or unwanted ink from your heat transfer.
- Shake, remove, or cut off any extra adhesion powder from the transfer paper.
- Check the back of the transfer, if there is any ink make sure to use a Teflon Sheet or computer paper on top, so the ink does not transfer to the heat press.
- Preheat your Heat Press's bottom pallet.

### **INSTRUCTIONS**

- Set your Heat Press to 340 degrees Fahrenheit.
- Preheat your garment (T-shirt) for approximately 6-10 seconds or until all moisture has left.
- With medium to heavy pressure, press the heat transfer for 12-13 seconds.
- Peel or remove the heat transfer immediately after releasing the heat press.

## **INTO THE WILD SCREEN PRINTING PLASTISOL HEAT TRANSFER INSTRUCTIONS**

### **PRE USE INSTRUCTIONS**

- Cut off any excess or unwanted ink from your heat transfer.
- Shake, remove, or cut off any extra adhesion powder from the transfer paper.
- Check the back of the transfer, if there is any ink make sure to use a Teflon Sheet or computer paper on top, so the ink does not transfer to the heat press.
- Preheat your Heat Press's bottom pallet.

### **INSTRUCTIONS**

- Set your Heat Press to 340 degrees Fahrenheit.
- Preheat your garment (T-shirt) for approximately 6-10 seconds or until all moisture has left.
- With medium to heavy pressure, press the heat transfer for 12-13 seconds.
- Peel or remove the heat transfer immediately after releasing the heat press.